

Note

All work should be done by a qualified mechanic and/or per an authorized shop manual for your make and model of motorcycle.

1. Remove shocks per steps outlined in your shop manual.
2. Press out the old bushings in a vise by using a socket that matches the diameter of the shock eye, and one slightly smaller than the inside diameter of the shock eye.
3. Press the new polyurethane bushings into the shock eye using the same technique as when removing them. Lubricating the bushings with a solution of soap and water will ease installation.
4. Install the shocks back onto the motorcycle per shop manual.